



iRobot Roomba 655 Pet Series Front Face Plate Replacement

How to remove that shiny silver front face plate on your Roomba

Written By: Rhett



INTRODUCTION

Removing this silver casing will give you access to the screws on the inner face plate beneath. Removing this is your first step.

Step 1 — Front Face Plate



- Remove the dust bin by pushing on the button for the dust bin removal
- Pull the dust bin out

Step 2



- Pull up on the silver handle to release the top protectant plastic
- Remove the top plastic carefully

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-21 04:14:01 PM.